



PIR Ready7 VT76x7 Series Programmable & Non-Programmable Thermostats For Commercial HVAC Applications

LonWorks Integration Manual ITG-VT760x7-PIR-LON-E01 (028-6007 R1 - Issue Date: May 30, 2008)



Product Overview

The VT76x7 PI thermostat family is specifically designed for single stage and multi-stage control of heating/cooling equipment such as rooftop and self-contained units with humidifier and/or dehumidifier. The product features an embedded complete humidity solution with an intuitive, menu-driven, backlit LCD display that walks users through the programming steps, making the process extremely simple. Accurate temperature & relative humidity control is achieved due to the product's PI time proportional control algorithm, which virtually eliminates temperature offset associated with traditional, differential-based thermostats.

All models contain one digital input, which can be set by the user to monitor filter status, activate a remote temporary occupancy switch, and/or used as a general purpose service indicator. The two models contain a SPST auxiliary switch, which can be used to control lighting or disable the economizer function and a discharge air sensor input.

The thermostats are also compatible with the new Viconics PIR cover accessories. Thermostats equipped with a PIR cover provide advanced active occupancy logic, which will automatically switch occupancy levels from Occupied to Stand-By and Unoccupied as required by local activity being present or not. This advanced occupancy functionality provides advantageous energy savings during occupied hours without sacrificing occupant comfort. All thermostats can be ordered with or without a factory installed PIR cover.



Fig.1 VT76x7B Thermostat

The additional following documentation is available on www.viconics.com

- Detailed information on the thermostat (VT76x7X5x00) is available in document *LIT-VT76x7-PIR-Exx*
- PIR application information and examples, are available on document: *APP-VT76-PIR-Guide-Exx*
- PIR cover installation information is available on document: *PIR Cover Installation-Exx*

Contents

- PID History Revision Table
- Thermostat Objects
- SNVTs and SCPTs Table Per Model
- Input Network Variables (nvi's) Description
- Output Network Variables (nvo's) Description
- Configuration Properties (nci's) Description
- Integration - Global Commands
- Integration - Graphic User Interface (GUI) Objects
- Integration - Configuration Objects
- Wiring Guide
 - Overview
 - Network Configuration
 - Maximum Number Of Devices
 - Maximum Cable Length
 - Repeaters
 - Terminators
- Network Adapter
- Software Files
- RoHS and Non-RoHS APB and NXE Files
- Device Identification
- Tips And Things You Need To Know
- Troubleshooting Section
- Document Control

PID History Revision Table


XIF, APB and NXE File Names and Corresponding PIDs. This manual information is to be used only with the current released VT76x7 PIR ready thermostats.

Used on current released thermostat	APB / NXE / XIF file names	Revision Level	Associated PID
PIR Ready VT76x7 Series	VT76RH_PIR.XIF	Rev 4.0	80:00:C5:55:00:04:04:22

This manual information is **NOT** to be used only with the previously released VT76x7 thermostats.

Previously released thermostat	APB / NXE / XIF file names	Revision Level	Associated PID
VT76x7 Series	VT76x7.XIF	Rev 3.0	80:00:C5:55:00:04:04:13

Thermostat Objects



SNVTs¹ and SCPTs² Table Per Model

No	Sub	Point Name	Snivet Type Enumeration and Signature Type	VT7657B5x00E	VT7607B5x00E
0		nviSpaceTemp	SNVT_temp_p	X	X
1		nviOutdoorTemp	SNVT_temp_p	X	X
2		nviOccManCmd	SNVT_occupancy	X	X
3		nviApplicMode	SNVT_hvac_mode	X	X
4		nviSetpoint	SNVT_temp_p	X	X
5		nviTimeSet	SNVT_time_stamp	X	N/A
6		nciDaySched[0]	UNVT_day_sched	X	N/A
7		nciDaySched[1]	UNVT_day_sched	X	N/A
8		nciDaySched[2]	UNVT_day_sched	X	N/A
9		nciDaySched[3]	UNVT_day_sched	X	N/A
10		nciDaySched[4]	UNVT_day_sched	X	N/A
11		nciDaySched[5]	UNVT_day_sched	X	N/A
12		nciDaySched[6]	UNVT_day_sched	X	N/A
13		nciSetPts	SNVT_temp_setpt	X	X
	1	occupied_cool		x	x
	3	unoccupied_cool		x	x
	4	occupied_heat		x	x
	6	unoccupied_heat		x	x
14		nciCfg1RtuHp	UNVT_cfg_1_rtu_hp	X	X
Associate with UNVT_cfg_1_rtu_hp format file					
	1	password	Unsigned-Long	x	x
	2	unoccupied_timer	Unsigned-Short	x	x
	3	anticycle	Unsigned-Short	x	x
	4	power_up_delay	Unsigned-Short	x	x
	5	temporary_occ_time	Unsigned-Short	x	x
	6	heating_stages_CPH	Unsigned-Short	x	x
	7	cooling_stages_CPH	Unsigned-Short	x	x
	8	heat_maximum_setpoint	SNVT_temp_p	x	x
	9	cool_minimum_setpoint	SNVT_temp_p	x	x
	10	OA_temp_heat_lockout	SNVT_temp_p	x	x
	11	OA_temp_cool_lockout	SNVT_temp_p	x	x
	12	calib_room_sensor	SNVT_temp_diff_p	x	x
	13	calib_outside_air_sensor	SNVT_temp_diff_p	x	x
	14	deadband	Unsigned-Short	x	x
	15	fan_mode	Enumeration Set Used: fan_mode_b-t	x	x
	16	fan_control	Enumeration Set Used: off_on_state_t	x	x
	17	fan_delay	Enumeration Set Used: off_on_state_t	x	x
	18	keypad_lockout	Enumeration Set Used: rem_lock_t	x	x
	19	proportional_band	Unsigned-Short	x	x
	20	temperature_units	Enumeration Set Used: temp_unit_t	x	x
	21	frost_protection	Enumeration Set Used: off_on_state_t	x	x
	22	menu_scroll	Enumeration Set Used: scroll_type_t	x	x

1: SNVTs: Standard Network Variables Types
 2: SCPTs: Standard Configuration Parameters Types

No	Sub	Point Name	Snivet Type Enumeration and Signature Type	VT7657B5x00E	VT7607B5x00E
15		nciCfg3RtuHp	UNVT_cfg_3_rtu_rh	X	X
Associate with UNVT_cfg_3_rtu_rh format file					
	1	di_config	Enumeration Set Used: input_cfg_model_d_t	x	x
	2	aux_contact_config	Enumeration Set Used: aux_contact_cfg_t	x	x
	3	number_of_events	Enumeration Set Used: nb_of_events_t	x	N/A
	4	progressive_recovery	Enumeration Set Used: off_on_state_t	x	N/A
	5	number_of_heating_stages	Unsigned-Short	x	x
	6	number_of_cooling_stages	Unsigned-Short	x	x
	7	rh_frontal_display	Enumeration Set Used: off_on_state_t	x	x
	8	humid_low_reset_temp	SNVT_temp_p	x	x
	9	humid_high_reset_temp	SNVT_temp_p	x	x
	10	dehum_lockout_temp	SNVT_temp_p	x	x
	11	humidification_high_limit_setpoint	SNVT_lev_percent	x	x
	12	humid_low_reset_rh_setpoint	SNVT_lev_percent	x	x
	13	dehumidification_hysterisys	SNVT_lev_percent	x	x
	14	rh_sensor_calibration	Signed-Long	x	x
	15	humidification_setpoint	SNVT_lev_percent	x	x
	16	dehumidification_setpoint	SNVT_lev_percent	x	x
	17	dehumidification_lockout_function	Enumeration Set Used: off_on_state_t	x	x
16		nciHvacType	SNVT_hvac_type	X	X
17		nciSccModel	UNVT_model_info_2	X	X
Associate with UNVT_model_info_2 format file					
		Thermostat Model		x	x
		Software Version		x	x
18		nvoSpaceTemp	SNVT_temp_p	X	X
19		nvoUnitStatus	SNVT_hvac_status	X	X
		mode		x	x
		heat_output_primary		x	x
		heat_output_secondary		N/A	N/A
		cool_output		x	x
		econo_output		N/A	N/A
		Fan_output		x	x
		in_alarm		x	x
20		nvoOutdoorTemp	SNVT_temp_p	X	X
21		nvoEffectOccup	SNVT_occupancy	X	X
22		nvoSccStatus	UNVT_thermo_state_rtu_rh	X	X
Associate with UNVT_thermo_state_rtu_rh format file					
	1	fan_output	True bit index 2	x	x
	2	cooling_stage_1	True bit index 3	x	x
	3	cooling_stage_2	True bit index 4	x	x
	4	auxiliary_contact	True bit index 5	x	x
	5	heating_stage_1	True bit index 6	x	x
	6	heating_stage_2	True bit index 7	x	x
	7	di_direct_status	True bit index 17	x	x
	8	local_pir_motion	True bit index 24	x	x
	9	service_alarm	True bit index 12	x	x
	10	filter_alarm	True bit index 13	x	x
	11	fan_lock_alarm	True bit index 25	x	x
	12	set_clock_alarm	True bit index 22	x	x
	13	frost_protection_alarm	True bit index 23	x	x

No	Sub	Point Name	Snivet Type Enumeration and Signature Type	VT7657B5x00E	VT7607B5x00E
23		nvoRHStatus	UNVT_rh_status	X	X
Associate with UNVT_rh_status format file					
		local_humidity_level	SNVT_lev_percent	x	x
		supply_humidity_level	SNVT_lev_percent	x	x
		effective_reset_humid_setpoint	SNVT_lev_percent	x	x
		pi_humid_demand_output	SNVT_lev_percent	x	x
		dehumid_output_active	Enumeration Set Used: off_on_state_t	x	x
24		nvoEffectSetpt	SNVT_temp_p	X	X
25		nvoSetpoint	SNVT_temp_p	X	X
26		nciSndHrtBt	SNVT_time_sec	X	X
27		nciMinOutTm	SNVT_time_sec	X	X
28		nciRcvHrtBt	SNVT_time_sec	X	X
29		nciMajVer	SCPT_maj_ver	X	X
30		nciMinVer	SCPT_min_ver	X	X

Input Network Variables (nvi's) Description

Parameter	Variable Name	Function
Room Temperature	network input SNVT_temp_p nviSpaceTemp	<ul style="list-style-type: none"> ➤ This input network variable provides a network remote temperature value to the thermostat. If a valid value is present, the internal temperature reading (internal sensor) is no longer used. ➤ Valid Range: -40 to 122°F (-40 to 50°C) ➤ Default Null (release) Value: 621.81°F (327.67°C or 0x7FFF) ➤ This network variable is subject to the Receive HeartBeat Time, nviRcvHrtBt.
Outdoor Air Temperature	network input SNVT_temp_p nviOutdoorTemp	<ul style="list-style-type: none"> ➤ This input network variable provides outdoor air temperature information to the thermostat from a network value temperature value. If a valid value is present, the internal temperature reading (internal sensor) is no longer used. The device will automatically display the value on its display when used. ➤ Valid Range: -40 to 122°F (-40 to 50°C) ➤ Default Null (release) Value: 621.81°F (327.67°C or 0x7FFF)
Occupancy	network input SNVT_occupancy nviOccManCmd	<ul style="list-style-type: none"> ➤ This input network variable is used to command the Space Comfort Controller into different occupancy modes. It is typically set by a supervisory node to manually control occupancy modes, or to override the scheduled occupancy. ➤ Default Null Value: OC_NUL = 0xFF ➤ Valid Range: <ul style="list-style-type: none"> 0 = OC_OCCUPIED 1 = OC_UNOCCUPIED 2 = OC_BYPASS – Not Used 3 = OC_STANDY – Not Used 0xFF = OC_NUL (Release to internal occupancy)** <p>* OC_OCCUPIED and OC_UNOCCUPIED commands will always have full authority over the local occupancy routines of the thermostat may they be a local input or a PIR cover.</p> <p>** OC_NUL command will release the thermostat to use its own internal occupancy routine driven by the local schedule, one of the digital input or a PIR cover installed on board.</p>
System Mode	network input SNVT_hvac_mode nviApplicMode	<ul style="list-style-type: none"> ➤ This network variable input is used to coordinate the Space Comfort Controller with any node that may need to control the heat/cool changeover of the unit. ➤ Default Null Value: HVAC_AUTO. ➤ This network variable is subject to the receive heartbeat time, nciRcvHrtBt ➤ Valid Range: <ul style="list-style-type: none"> 0 = HVAC_AUTO 1 = HVAC_HEAT 2 = HVAC_MRNG_WRMUP – Not Used 3 = HVAC_COOL 4 = HVAC_NIGHT_PURGE – Not Used 5 = HVAC_PRE_COOL – Not Used 6 = HVAC_OFF 7 = HVAC_TEST – Not Used 8 = HVAC_EMERG_HEAT – Not Used 9 = HVAC_FAN_ONLY – Not Used 12 = HVAC_MAX_HEAT – Not Used 13 = HVAC_ECONOMY – Not Used 14 = HVAC_DEHUMID – Not Used 15 = HVAC_CALIBRATE – Not Used 0xFF = HVAC_NUL – Not Used

Parameter	Variable Name	Function																												
Occupied Cool & Heat Setpoints	network Input SNVT_temp_p nviSetpoint	<ul style="list-style-type: none"> ➤ This input network variable is used to allow the occupied temperature setpoints only to be changed via the network from a single analog value. (Note: the Unoccupied setpoints are not changed). The corresponding heating and cooling values are derived from the minimum deadband configuration value ➤ Default Null Value: 621.81°F (327.67°C or 0x7FFF) ➤ Ex. If the minimum deadband configuration value = 2 °F and nviSetpoint = 70°F. <ul style="list-style-type: none"> • The resulting Occupied heating setpoint will equal 69 °F which is derived from 70 °F minus ½ the minimum deadband configuration value of 2 °F The resulting Occupied cooling setpoint will equal 71 °F which is derived from 70 °F plus ½ the minimum deadband configuration value of 2 °F 																												
Date and time	network input SNVT_time_stamp nviTimeSet	<ul style="list-style-type: none"> ➤ This input network variable is used to set the time and date of the Space Comfort Controller. ➤ Default Null Value : <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Sub</th> <th>Name</th> <th>Valid Range</th> <th>Default Value</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>year</td> <td>0 to 3000</td> <td>0</td> </tr> <tr> <td>2</td> <td>month</td> <td>0 to 12</td> <td>0</td> </tr> <tr> <td>3</td> <td>day</td> <td>0 to 31</td> <td>0</td> </tr> <tr> <td>4</td> <td>hour</td> <td>0 to 23</td> <td>0</td> </tr> <tr> <td>5</td> <td>minute</td> <td>0 to 59</td> <td>0</td> </tr> <tr> <td>6</td> <td>second</td> <td>0 to 59</td> <td>0</td> </tr> </tbody> </table>	Sub	Name	Valid Range	Default Value	1	year	0 to 3000	0	2	month	0 to 12	0	3	day	0 to 31	0	4	hour	0 to 23	0	5	minute	0 to 59	0	6	second	0 to 59	0
Sub	Name	Valid Range	Default Value																											
1	year	0 to 3000	0																											
2	month	0 to 12	0																											
3	day	0 to 31	0																											
4	hour	0 to 23	0																											
5	minute	0 to 59	0																											
6	second	0 to 59	0																											

Output Network Variables (nvo's) Description

All output network variables will be updated no faster than the Minimum Send Time (nciMinOutTm) configuration value, if used.

An output network variable will be transmitted immediately when its value has changed significantly.

Additionally, this variable will also be transmitted as a heartbeat output on a regular basis as dictated by the Maximum Send Time (nciSndHrtBt) configuration value.

Parameter	Variable Name	Function		
Room Temperature	network output SNVT_temp_p nvoSpaceTemp	<ul style="list-style-type: none"> ➤ This output network variable is used to monitor the effective space temperature sensor that the Space Comfort Controller is using for control. This output echoes the value of the input. ➤ Valid Range: -40 to 122°F (-40 to 50°C) ➤ The value 621.07°F (327.67°C or 0x7FFF) will be sent as an invalid value in case of a sensor failure. 		
Unit Status	network output SNVT_hvac_status nvoUnitStatus	<ul style="list-style-type: none"> ➤ This output network variable is available to report the Space Comfort Controller status. It combines the operating mode, the capacity of heating and cooling used and an indication if any alarms are present in the object. 		
		Sub	Name	Valid Value
		01	mode	HVAC_HEAT HVAC_MRNG_WRMUP – Not Used HVAC_COOL HVAC_NIGHT_PURGE – Not Used HVAC_PRE_COOL – Not Used HVAC_HVAC_OFF HVAC_HVAC_TEST – Not Used HVAC_HVAC_EMERG_HEAT – Not Used HVAC_FAN_ONLY – Not Used HVAC_MAX_HEAT – Not Used
		02:	heat_output_primary	0-100%
		03	heat_output_secondary	Not Used
		04	cool_output:	0-100%
		05	econ_output	Not Used
		06	fan_output	0-100%
		07	In_alarm	0 (No alarms) 1 (Alarm On) 0x7FF (Alarming disabled) – Not Used
Outdoor Temperature	network output SNVT_temp_p nvoOutdoorTemp	<ul style="list-style-type: none"> ➤ This output network variable is used to monitor the outdoor air temperature. ➤ Valid Range: -40 to 122°F (-40 to 50°C) ➤ The value 621.07°F (327.67°C or 0x7FFF) will be sent as an invalid value in case of a sensor failure or if unconnected. 		

Parameter	Variable Name	Function																																										
Occupancy	network output SNVT_occupancy nvoEffectOccup	<ul style="list-style-type: none"> ➤ This output network variable is used to indicate the actual occupancy mode of the unit. This information is typically reported to a supervisory controller or provided to another Space Comfort Controller to coordinate the operation of multiple units ➤ Valid Range: <ul style="list-style-type: none"> 0 = OC_OCCUPIED 1 = OC_UNOCCUPIED 2 = OC_BYPASS¹ 3 = OC_STANDBY – Not Used <p>NOTE : OC_BYPASS can be initiated by either nviOccManCmd or a local input. NvoEffectOccup will only be in OC_BYPASS for the duration of the ToccTime (nciGenOpts), until reinitiated by either a transition of the local input or an update to nviOccManCmd.</p>																																										
Thermostat's I/O status	network output UNVT_thermo_state_rh nvoSccStatus	<ul style="list-style-type: none"> ➤ This network variable output is used to report the Space Comfort Controller inputs' and outputs' status. 																																										
		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Name</th> <th style="width: 25%;">Valid value</th> <th style="width: 25%;">True Bit Index</th> </tr> </thead> <tbody> <tr> <td>fan output</td> <td>0 = Off 1 = On</td> <td>2</td> </tr> <tr> <td>cooling stage 1</td> <td>0 = Off 1 = On</td> <td>3</td> </tr> <tr> <td>cooling stage 2</td> <td>0 = Off 1 = On</td> <td>4</td> </tr> <tr> <td>auxiliary contact</td> <td>0 = Off 1 = On</td> <td>5</td> </tr> <tr> <td>heating stage 1</td> <td>0 = Off 1 = On</td> <td>6</td> </tr> <tr> <td>heating stage 2</td> <td>0 = Off 1 = On</td> <td>7</td> </tr> <tr> <td>di1 direct status</td> <td>0 = Activated 1 = Not Activated</td> <td>17</td> </tr> <tr> <td>local pir motion</td> <td>0 = No motion 1 = Motion</td> <td>24</td> </tr> <tr> <td>service alarm</td> <td>0 = Off 1 = On</td> <td>12</td> </tr> <tr> <td>filter alarm</td> <td>0 = Off 1 = On</td> <td>13</td> </tr> <tr> <td>fan lock alarm</td> <td>0 = Off 1 = On</td> <td>25</td> </tr> <tr> <td>set clock alarm</td> <td>0 = Off 1 = On</td> <td>22</td> </tr> <tr> <td>frost protection alarm</td> <td>0 = Off 1 = On</td> <td>23</td> </tr> </tbody> </table>	Name	Valid value	True Bit Index	fan output	0 = Off 1 = On	2	cooling stage 1	0 = Off 1 = On	3	cooling stage 2	0 = Off 1 = On	4	auxiliary contact	0 = Off 1 = On	5	heating stage 1	0 = Off 1 = On	6	heating stage 2	0 = Off 1 = On	7	di1 direct status	0 = Activated 1 = Not Activated	17	local pir motion	0 = No motion 1 = Motion	24	service alarm	0 = Off 1 = On	12	filter alarm	0 = Off 1 = On	13	fan lock alarm	0 = Off 1 = On	25	set clock alarm	0 = Off 1 = On	22	frost protection alarm	0 = Off 1 = On	23
		Name	Valid value	True Bit Index																																								
		fan output	0 = Off 1 = On	2																																								
		cooling stage 1	0 = Off 1 = On	3																																								
		cooling stage 2	0 = Off 1 = On	4																																								
		auxiliary contact	0 = Off 1 = On	5																																								
		heating stage 1	0 = Off 1 = On	6																																								
		heating stage 2	0 = Off 1 = On	7																																								
		di1 direct status	0 = Activated 1 = Not Activated	17																																								
		local pir motion	0 = No motion 1 = Motion	24																																								
		service alarm	0 = Off 1 = On	12																																								
		filter alarm	0 = Off 1 = On	13																																								
		fan lock alarm	0 = Off 1 = On	25																																								
set clock alarm	0 = Off 1 = On	22																																										
frost protection alarm	0 = Off 1 = On	23																																										

Parameter	Variable Name	Function	
Thermostat's I/O status	network output UNVT_rh_status nvoRHStatus	This network variable output is used to report the Space Comfort humidity function's status	
		Name	Valid value
		local humidity level	0 to 100% RH
		supply humidity level	0 to 100% RH
		effective reset humid setpoint	0 to 100% RH
		pi humid demand output	0 to 100% demand
		dehumid output active	0 = Dehumidification not active 1 = Dehumidification active
Setpoint	network output SNVT_temp_p nvoEffectSetpt	<ul style="list-style-type: none"> ➤ This output network variable is used to monitor the effective temperature setpoint which may depend on nciSetpoints, nvoEffectOccup, nviSetpoint and any local setpoint adjustment. For example, if the occupancy state is unoccupied and the heat/cool state is heat, the effective setpoint would be equal to the unoccupied heating setpoint defined in nciSetpoints. ➤ Valid Range: -40 to 100°F (-40 to 37.5°C) 	
Local setpoint output	network output SNVT_temp_p nvoSetPoint	<ul style="list-style-type: none"> ➤ This output network variable is used to monitor the space temperature setpoint ➤ Valid Range : 40°F to 100°F (4.5°C to 37.5°C) ➤ The present value is derived by the following OccHeat Setpoint + ((OccCool Setpoint – OccHeat Setpoint) / 2) 	

Configuration properties (nci's) Description

Parameter	Variable Name	Function			
Schedule	network input config UNVT_day_sched nciDay_Sched[x] x = 0 to 6	<ul style="list-style-type: none"> ➤ This configuration property defines the schedule for every day of the week (from Monday to Sunday or from day 0 to day 6). This nci is linked with the nvoEffectOccup variable. ➤ 2 or 4 events can entered depending on the nb_of_events variable. ➤ Starting and ending time are entered in minutes, e.i. 11:59 pm is equal to 1439 minutes (23 hours * 60 min + 59 min) ➤ Valid Range : 0 to 1439 minutes ➤ Default values: 			
		Sub	Name	Default Value	
		1	occupied_event_1	0	
		2	unoccupied_event_2	1439	
		3	occupied_event_3	0	
4	unoccupied_event_4	1439			
Temperature Setpoints	network input config SNVT_temp_setpt nciSetPts	<ul style="list-style-type: none"> ➤ This configuration property defines the space temperature setpoints for various heat, cool and occupancy modes. ➤ The stand-by setpoints can be modified but are not used by the controller, as it does not support Stand-By occupancy mode. ➤ Valid Range and Default values: 			
		Sub	Name	Valid Range	Default value
		01	occupied_cool	54 to 100°F (12 to 37.5°C)	73.5°F (23°C)
		02	standby_cool	Not Used	Not Used
		03	unoccupied_cool	54 to 100°F (12 to 37.5°C)	82.5°F (28°C)
		04	occupied_heat	40 to 90°F (4.5 to 32°C)	70°F (21°C)
		05	standby_heat	Not Used	Not Used
		06	unoccupied_heat	40 to 90°F (4.5 to 32°C)	61°F (16°C)
Thermostat's common configuration parameters network input config	UNVT_cfg_1_rtu_hp nciCfg1RtuHp	<ul style="list-style-type: none"> ➤ This configuration property defines the thermostat's common configuration parameters and their settings. ➤ Valid Range and Default values: 			
		Name	Valid Range	Default value	
		password	0 to 1000	0	
		unoccupied timer	0.5 to 24.0 hours	0.5	
		anticycle	0, 1, 2, 3, 4, or 5 minutes	2 minutes	
		power-up delay	10 to 120 sec.	10 sec.	
		temporary occ time	0, 1, 2, 3 to 12 hours	3 hours	
		heating stages cph	3, 4, 5, 6, 7 or 8 CPH	4 CPH	
		cooling stages cph	3 or 4 CPH	4 CPH	
		heat maximum setpoint	40 to 90°F (4.5 to 32°C)	90°F	
		cool minimum setpoint	54 to 100°F (12 to 37.5°C)	54°F	
		oa temp heat lockout	-15 to 120°F (-26 to 49°C)	120°F	
		oa temp cool lockout	-40 to 95°F (-40 to 35°C)	-40°F	
		calib room sensor	±5°F (±2.5°C)	0°F	
		calib outdoor air sensor	±5°F (±2.5°C)	0°F	
		deadband	2 to 4°F with 1°F increments (1 to 2°C)	2°F	

Parameter	Variable Name	Function			
Thermostat's common configuration parameters network input config	UNVT_cfg_3_rtu_hp nciCfg3RtuHp	fan mode	0 = On 1 = Auto 2 = Smart	0 = On	
		fan control	0 = Off 1 = On	1 = On	
		fan delay	0 = Off 1 = On	0 = Off	
		keypad lockout	0 = No_Lockout 1 = Level_1 2 = Level_2	No_Lockout	
		proportional band	2 to 8 F	2 F	
		temperature units	0 = °C 1 = °F	°F	
		frost protection	0 = Off 1 = On	0 = Off	
		temperature scale	0 = °C 1 = °F	°F	
		➤ This configuration property defines the thermostat's common configuration parameters and their settings. Valid Range and Default values:			
		Name	Valid Range	Default value	
		di1 configuration	0 = None 1 = RemNSB 2 = RemOVR 3 = Filter 4 = Service	0 = None	
		auxiliary contact configuration	0 = NORMALLY_OPEN 1 = NORMALLY_CLOSE	0 = NORMALLY_OPEN	
		number of events	2 or 4	2	
		progressive recovery enable	0 = Off 1 = Active	0 = Off	
		number of heating stages	1 = 1 Stage 2 = 2 Stages	2	
		number of cooling stages	1 = 1 Stage 2 = 2 Stages	2	
		rh frontal display	0 = Off 1 = On	Off	
		humid low reset temp	-40°F up to 15°F (-40°C to -9.5°C)	-20.2°F (-29°C)	
		humid high reset temp	20°F to 55°F (-6.5°C to 13°C)	32°F (0°C)	
		dehumidification lockout temp	-40°F to 122°F (-40°C to 50°C)	32°F (0°C)	
		humidification high limit setpoint	50% RH to 90% RH	85% RH	
		humid low reset rh setpoint	10% RH to 90% RH	20% RH	
		dehumidification hysteresis	2% RH to 20% RH	5% RH	
		rh sensor calibration	-15% RH to 15% RH	0% RH	
		humidification setpoint	10% RH to 90% RH	50% RH	
		dehumidification setpoint	15% RH to 95% RH	70% RH	
		dehumidification lockout function	0 = Off 1 = On	1 = On	

Parameter	Variable Name	Function			
HVAC Unit-Type Identifier	network input config SNVT_hvac_type nciHvacType	<ul style="list-style-type: none"> ➤ This configuration property helps the user identify the type of equipment being monitored. ➤ Valid Range: 			
		Value	Identifier	Name	
		0	HVT_GENERIC – Not Used	Generic	
		1	HVT_FAN_COIL	Fan Coil	
		2	HVT_VAV – Not Used	Variable Air Volume Terminal	
		3	HVT_HEAT_PUMP	Heat Pump	
		4	HVT_ROOFTOP	Rooftop Unit	
		5	HVT_UNIT_VENT – Not Used	Unit Ventilator	
		6	HVT_CHIL_CEIL – Not Used	Chilled Ceiling	
		7	HVT_RADIATOR – Not Used	Radiator	
8	HVT_AHU – Not Used	Air Handling Unit			
9	HVT_SLF_CONT – Not Used	Self-Contained Unit			
Thermostat's model number	network input config UNVT_model_number nciSccModel	<ul style="list-style-type: none"> ➤ This configuration property defines model number and software version of the thermostat ➤ Valid Range and Default values: 			
		Sub	Name	Valid Range	Default value
		01	Thermostat Model	00 = VT7657B1000E 17 = VT7607B1000E	Depend on model being used
		02	Software Version	Unsigned short	Thermostat dependent
Maximum Send Time	network input config SNVT_time_sec nciSendHrtBt	<ul style="list-style-type: none"> ➤ This configuration property defines the maximum period of time that expires before the specified network variable outputs will automatically be updated ➤ Valid Range: 0 sec. To 6553.4 sec.. Setting nciSendHrtBt to 0 disables the Send Heartbeat mechanism. ➤ Default Null Value : 0.0 sec (no automatic update) 			
Minimum Send Time	network input config SNVT_time_sec nciMinOutTm	<ul style="list-style-type: none"> ➤ This configuration property defines the minimum period of time between automatic network variable outputs transmissions. ➤ Valid Range: 0 sec. to 6553.4 sec.. Setting nciRcvHrtBt to 0 disables the Minimum Send Time mechanism. ➤ Default Null Value : 0.0 sec (no minimum send time) 			
Minimum Receive Time	network input config SNVT_time_sec nciRcvHrtBt	<ul style="list-style-type: none"> ➤ This configuration property is used to control the maximum time that elapses after the last update to a specified network variable input before the Space Comfort Controller starts to use its default values. ➤ Valid Range: 0 sec. to 6553.4 sec.. Setting nciRcvHrtBt to 0 disables the Receive Heartbeat mechanism. ➤ Default Null Value : 0.0 sec (no failure detected) 			
Hardware or Software revisions	network input config SCPT_maj_ver nciMajVer	<ul style="list-style-type: none"> ➤ This configuration property defines the major module software revisions. ➤ Valid Range: 0 to 255 			
Hardware or Software revisions	network input config SCPT_min_ver nciMinVer	<ul style="list-style-type: none"> ➤ This configuration property defines the minor module software revisions. ➤ Valid Range: 0 to 255 			

Integration – Global Commands

The following figure shows which objects from the thermostat can be monitored and commanded from the BAS front-end.




Figure 1: Global commands from a BAS front-end to a VT76x7 series tstat

Integration – Graphic User Interface (GUI) Objects

The following objects should be typically used in a GUI:

- nvoSpaceTemp
- occupied_heat (nciSetpts);
- unoccupied_heat (nciSetpts);
- occupied_cool (nciSetpts);
- unoccupied_cool (nciSetpts);
- nvoOutdoorTemp
- nvoEffectOccup
- heat_output_primary (nvoUnitStatus)
- cool_output (nvoUnitStatus)
- fan (nvoSccStatus)
- cool_1 (nvoSccStatus)
- cool_2 (nvoSccStatus)
- heat_1 (nvoSccStatus)
- heat_2 (nvoSccStatus)
- Local_RH_level (nvoRHStatus)
- supply_RH (nvoRHStatus)
- effect_reset_RH_setpt (nvoRHStatus)
- PI_demand_humid_output (nvoRHStatus)
- dehumid_active (nvoRHStatus)
- service_alarm (nvoSccStatus)
- filter_alarm (nvoSccStatus)
- d1_direct (nvoSccStatus)
- frostpro_alarm (nvoSccStatus)




Figure 2: Graphical User Interface (GUI) example of a Roof Top Unit with dehumidification

Configuration Objects

The following SNVT and UNVT should be typically used for configuration purposes:

- nciCfg1RtuHp;
- nciSetpoints;
- nciCfg3RtuHp;
- nviDaySchedule[0]
- nviDaySchedule[1]
- nviDaySchedule[2]
- nviDaySchedule[3]
- nviDaySchedule[4]
- nviDaySchedule[5]
- nviDaySchedule[6]

Wiring Guide

Overview

For clarity we will use the term “Device” to represent any product with an active Echelon network connection, including Viconics and non-Viconics controllers.

Summary Specifications:

Parameter	Details
Network Wiring	24 to 16AWG, twisted pair
Maximum total wire length ¹	1600 feet (500 meters) in free topology
Maximum device-to-device distance	1600 feet (500 meters) in free topology
Polarity	Polarity insensitive
Multi-drop	Free Topology
Termination for Free Topology Network Segment	One RC network with $R_a = 52.3\Omega \pm 1\%$, 1/8W
Termination for Doubly Terminated Bus Network Segment	Two RC network with $R_a = 105\Omega \pm 1\%$, 1/8W
Number of transceivers per segment	Up to 64
Baud rate	78000 bits per second

¹Network segment length varies depending on wire type.

Table 1: Summary of Specifications for a Viconics' EIA-485 Network

Network Configuration

The Echelon network is designed to support free topology wiring and will accommodate bus, star, loop or any of these topologies. Echelon devices can be located at any point along the network wiring.

Figures 3.1 to 3.5 present five different network topologies. The actual termination circuit will vary by application.



Figure 3.1 Singly Terminated Bus Topology



Figure 3.2 Doubly Terminated Bus Topology



Figure 3.3 Star Topology




Figure 3.4 Loop Topology




Figure 3.5 Mixed Topology

Maximum Number Of Devices

Up to 64 transceivers are allowed per network segment. If your network requires more than 64 transceivers a repeater is then required to extend your network

Maximum Cable Length

The maximum length of a chain is related to its transmission speed. Using proper cable, Echelon supports a baud rate of 78 kilobits per second for distances up to 1600-ft (500 m) in free topology and 8800 ft (2700 m) in bus topology with double terminations.

If you require a maximum network length of more than 1600-ft (500 m) or 8800 ft (2700 m), then a repeater is required to extend the network.

Repeater

In the event that the limits on the number of transceivers or total wire distance are exceeded, a physical layer repeater can be added to interconnect two or more network segments. A repeater will double the overall channel capability, including node count and network extent, but not bandwidth. Note that only one physical layer repeater should be placed in series between any two nodes on a channel. If additional cabling or network bandwidth is required, then a LonWorks Router should be used in place of a repeater.

Terminators

Echelon network segments requires termination for proper data transmission performance. The type of terminator varies depending on whether shielded or unshielded cable is used. Free topology and Bus networks also differ in their termination requirements. The following sections describe the various terminators and terminations procedure.

Free Topology Network Segment

In a free topology segment, only one termination is required and may be placed anywhere on the free topology segment. There are two choices for the termination:

1. RC network with $R_a = 52\Omega \pm 1\%$, 1/8W
2. LPI-10 Link Power Interface, with jumper at "1 CPLR" setting.

Doubly Terminated Network Segment

In a doubly terminated bus topology, two terminations are required, one at each end of the bus. There are two choices for each termination:

1. RC network with $R_a = 105\Omega \pm 1\%$, 1/8W
2. LPI-10 Link Power Interface, with jumper at "2 CPLR" setting.

Only one LPI-10 interface is supported per segment. The other terminator must be an RC-type.

Grounding Shielded Twisted Pair Cable

When using Shielded Twisted Pair, terminate the twisted pair as listed in the previous section and ground the cable shield by using a capacitor, to tie the shield to earth ground, and a large-value resistor to bleed off any static charge on the shield. Tying the shield to earth ground through a capacitor will avoid DC and 50/60Hz ground paths from being formed through the shield. Typical values for resistor and capacitor are as follows:

Capacitor = 0.1 μ F, 10%, Metalized Polyester, $\geq 100V$

Resistor = 470k Ω , 1/4W, $\pm 5\%$

The cable shield should be grounded at least once per segment, and preferably at each node. Grounding the shield at every node will assist in suppressing 50/60Hz standing waves.

Network Adapter

Although network connections are polarity insensitive, it is good practice to keep polarity consistent throughout the entire site. Figure 4 shows a network connection example and the location of the Status LED. This Status LED may help to troubleshoot network problems.




Figure 4: Network connections and location of the Status LED on a LON module

Table 2 shows the different possibilities with the Status LED behavior of the LON module.

Condition of the Status LED	Explanation
➤ Continuously ON	The Echelon communication module has no valid application loaded in its memory.
➤ Flashing at a rate of 1/2Hz	The Echelon communication module has an application loaded in its memory but is Unconfigured. When an Echelon communication module is in the unconfigured state, the application is not running. This is the default state when the devices are shipped. A network management tool should be used to configure the module and integrate the device to a LonWorks network.
➤ Continuously OFF	The Echelon communication module has an application loaded into its memory and the application is running.

Table 2: Status LED condition

Software Files

XIF: When binding a node onto the network, an XIF file is needed. The XIF file has information that is used by the network management tool to help ease the installation and maintenance process of a node. It is also used for offline configuration of the node.

APB and NXE: When running an application program associated with a XIF file, an APB or NXE file is needed. Please note that the thermostats have the APB file already flashed from the factory.

Device Resource File (DRF): When a LON network management tool is used; a DRF file must be installed. DRF files are needed to display special manufacturer defined variables or configurations correctly.

- Please note that all release notes for the XIF, APB & NXE software files will be included under the following folder name on your hard drive: C:\LonWorks\Import\Viconics. The name of the file is: VT7xxxReadme.txt

Plug-Ins File: Plug-Ins simplify start-up, maintenance, configuration and reduce the installation effort.

- Please note that all release notes for Plug-Ins files will be included under the following folder name on your hard drive: C:\LonWorks\Plug-Ins\Viconics\VT7xxx. The name of the file is: Readme.txt.
- All the latest software files can be downloaded from VICONICS' web site at <http://www.viconics.com>

Device Identification

An Echelon device has a unique mechanism to identify itself, the Neuron ID, which is obtained during commissioning.

There are two ways of getting the Neuron ID: with a Service Pin or manually.

Service PIN

The Service PIN is used to identify the device at commissioning. By pressing simultaneously the “Yes” button and the “No” button located on the keypad interface of a VT7600 device, the program ID and the Neuron ID (LonWorks Unique ID) contained in the device are transmitted to the commissioning or service tool. The Status LED will blink when the device accepts the Service PIN command.

Figures 6 and 7 show an example of a Service PIN request made through a commissioning tool

The screenshot shows a software window titled "Add device" with a blue header bar. Inside, there are several input fields and buttons. The "New Device Name" section has a text box with "Device1". The "Device Identification Method" section has a dropdown menu showing "Service Pin" and a "Get" button next to a "Neuron ID" text box. The "Commission" section has a checked checkbox for "Commission Device". The "Location" section has an empty text box. The "Ping Interval" section has a dropdown menu showing "2 minutes". A red instruction reads "Click 'Get' button to begin ServicePin method." At the bottom, there are three buttons: "< Back", "Finish", and "Cancel".

Figure 6: Service Pin request through a commissioning tool

The screenshot shows a software window titled "Press Service Pin" with a blue header bar. The main area contains the text "Press the Service Pin on the device you wish to install!" in blue. At the bottom right, there is a "Cancel" button.

Figure 7: Service Pin request through a commissioning tool

Manual Identification

Neuron ID of a device can also be entered manually through a commissioning or service tool. Neuron ID should be located on the Echelon chip of the device being commissioned.

Figure 8 shows an example of a Manual Neuron ID request made through a commissioning tool.

Figure 8: Manual Neuron ID request

Tips And Things You Need To Know

- If the heartbeat is lost, the module will release the network sensor value for the Room Temperature (nviSpaceTemp) and the Outdoor Temperature (nviOutdoorTemp);
- The heartbeat parameter of a Tridium front-end should be set at the slowest configuration possible so that nviTimeStamp updates correctly;
- With any LNS Tools, nviTimeStamp should be set to refresh everyday or on power-up;
- Viconics recommend to use the provided Viconics format files as stipulated in the snivet per model table view

Troubleshooting Section

Error / Trouble Condition	Possible Cause	Solution
Thermostat does not come online	The LON network has too many devices.	Do not exceed the maximum number of devices and maximum length allowed by the EIA-485 specifications.
	Too many devices were installed without any repeaters.	Repeaters need to be installed as specified in this document.
	The LON cable runs are broken	Locate the break and correct wiring
	The thermostat does not have power	Apply power to the thermostat

Document Control

Document Name: ITG-VT76x7-PIR-LON-E01
 Document Filename: ITG-VT76x7-PIR-LON-E01.pdf

Revision	Date	Changes
00	May 30, 2008	Initial release
02	Feb 06, 2009	Added changes for new PID supported 80:00:C5:55:00:04:04:22 Added revision history table for all VT76x7 PID's